





LE 3/16 X 3/32




Spars 1/16 Sq.

TE 3/16 X 1/16.




1/16 Sht wing tips.




The nose leg.


An exercise to test your wire bending skills. I would suggest starting with the loop although it might be easier as a diamond shape.



Sandwich the main undercarriage legs between two full ribs.





Typical wing rib  
15 req from 1/16 Sht.



Wing saddle.

10



Undercarriage door  
1/32 Sheet.

*Bostonian.*  
*Piper Cherokee Arrow 200*

Sheet 2

